








Earbuds Status	Earbuds LED Indicator
Charging	LED stay red, OFF when fully charged (In charging box)
Connecting	Take out the earbuds, LED flashes fast blue (with a tone)
Connected	LED flashes blue once ever 10 seconds

Version: 2.4G Plug and Play














* No Bluetooth function, cannot connect to other devices.

Volume Control	Operation
Volume-	Click the left earbuds button to volume down
Volume+	Click the right earbuds button to volume up



Music mode / Gaming mode

Mode switch	Double click the left/right earbud twice to switch modes
Music mode	two beeps are for music mode
Game mode	One beep is for game mode (low latency)



项目名称	RT5114R1	备注	
物料名称	RT5114R1说明书	版本	No.:2.9
物料编号	07.695114001	制作	Winson
物料尺寸	110*105mm	日期	2024/11/07